

Instrukcja montażu zestawu crash padów dla: SUZUKI GS 500

KOD: CPS18R

Dziękujemy za zakup Crash padów naszej firmy dla motocykla Suzuki GS 500.

Zostały one zaprojektowane tak, aby zapewnić ochronę Państwa motocykla podczas ślizgu, przy pokonywaniu zakrętu lub upadku. Crash pady Womet-tech są produkowane przez firmę specjalizującą się w tego typu produktach. Charakteryzują się wytrzymałością na silne uderzenia, nie są łamliwe i bardzo dobrze pochłaniają energię uderzenia. Wielu Motocyklistów wybrało i przetestowało nasze produkty, pozytywnie oceniając ich jakość!

Przed rozpoczęciem pracy należy przeczytać uważnie całą instrukcję. Jeśli nie są państwo pewni montażu zaleca się kontakt z serwisem.

Zestaw zawiera:

2x śruba M10x90
1x Szpilka M10x260
2x tworzywo z aluminiową tuleją wewnątrz
2x Adapter aluminiowy 85M10
2x tuleja aluminiowa ustalająca
2x Podkładka
2x zaśleпка*



Instrukcja:

1. Upewnij się, że motocykl stoi pionowo, a silnik jest podparty.
2. Odkręć nakrętkę z prawej strony. Żeby to zrobić musisz skontrolować kluczem z lewej strony.
3. Wyjmij fabryczną śrubę z silnika.
4. Zainstaluj adapter aluminiowy 85M10 na pręt gwintowany.
5. Wsuń całość (pręt z crash padem) do miejsca gdzie była fabryczna śruba.
6. Z lewej strony na wystający pręt zakręć adapter aluminiowy 85M10.
7. Zamontuj Crash pad poprzez zakręcenie go do adaptera.

Gwarancja i ograniczenie odpowiedzialności.

Firma Womet- tech zastrzega sobie prawo do zmiany projektu bez wpływu na działanie czy estetykę Produktów i dostarczenie ich w takim stanie który będzie zgodny z zamówieniem. Kupujący uznaje, że żadnego rodzaju oświadczenie ani zapewnienie, inne niż wymienione w zamówieniu i jego potwierdzeniu, nie zostało złożone i nie będzie stosowane względem Produktów. Kupujący, dokonując zakupu Produktu, potwierdza jego jakość handlową oraz przydatność do określonego celu. Kupujący jest odpowiedzialny za zapewnienie nienaruszenia gwarancji motocykla podczas montowania Produktów. Wszystkie produkty rozprowadzane przez Womet-tech są opatrzone gwarancją dotyczącą wyłącznie wad materiałowych i wad wykonania. Wszelkie reklamacje zostaną rozpatrzone bezzwłocznie i rzetelnie. Przy zwrocie Produktów z usterką Womet-tech zapewnia ich wymianę lub zwrot pieniędzy tylko w przypadku, jeżeli Produkt nie podlegał jakiegokolwiek modyfikacji i był wykorzystywany zgodnie z instrukcjami lub zaleceniami producenta oraz jeżeli wada nie powstała na skutek wypadku lub zaniedbania. Producent nie ponosi odpowiedzialności za szkody na osobie oraz szkody na mieniu jak również szkody pośrednie wynikające z testowania oraz użytkowania produktów.

Tel.12-350-41-05

www.womet-tech.pl

e-mail biuro@womet-tech.pl

* Dostępne opcjonalnie. Od 2013r dołączone do zestawu.

Crash Protector Kit Installation Instructions for SUZUKI GS 500

CODE: CPS18R

Thank you for purchasing the Crash Protectors for SUZUKI GS 500. They were designed for effective protection of your motorcycle against damage when sliding, taking bends or crashing. Womet-tech Crash Protectors are manufactured by the company specializing in such products. They are strong impact resistant, flexible and able to dissipate the crash impact. Our Crash Protectors have been used and recommended by many motorcyclist!

It is essential to read the entire Installation Instructions carefully. If in any case you are not certain of how to install the kit, contact service.

Parts included:

2x M10x90 bolt
1x M10x260 steel bar
2x plastic with aluminium bushing pressed inside
2x aluminium adapter 85M10
2x aluminium spacer
2x washer
2x plastic cap with sticker*



Instructions:

1. Make sure the bike is standing stable and the engine is supported.
2. Screw off and remove the right-side nut (right-side when sitting on a bike). A wrench must be used to hold the screw on the left side.
3. Remove the mount bolt of the engine.
4. Mount the aluminium adapter on the bar.
5. Replace the factory bolt with the set (the bar with Crash Protector).
6. Mount the aluminium adapter 85M10 on the sticking out part of the bar on the left side of the bike.
7. Mount the crash protector on the aluminium adapter.

Guarantee and limitation of liability

Womet-tech reserves the right to modify the design, however without influencing any functions or aesthetics of the Products and to deliver them in a condition that complies with the order. Whereas, the Buyer acknowledges that any statement or guarantee other than stated in the order and its confirmation has not been made and shall not be applied to the Products. The Buyer, by purchasing the Product recognizes its commercial quality and its specific usability. The Buyer is responsible for any damages to the motorcycle caused during the installation of Products. All Products distributed by Womet-tech are covered by the guarantee against defects in the material and in manufacturing solely. All complaints shall be addressed immediately and properly. In case faulty Products are returned, Womet-tech guarantees the replacement of such Products or the refund, providing that the Product was not modified in any way and was used in compliance with the instructions or manufacturer's recommendations and if the fault was not caused by neglect or accident. The manufacturer does not bear the liability for any damages either to the person or property or damages resulting from testing or normal wear and tear of Products.

Phone: 12-350-41-05

www.womet-tech.pl

e-mail biuro@womet-tech.pl

* Available optionally. Included to the kit from 2013.