

Instrukcja montażu Crash-Protektorów: YAMAHA YZF R1 09- KOD: CPY22S

Dziękujemy za zakup Crash padów naszej firmy dla motocykla Yamaha YZF R1 .

Zostały one zaprojektowane tak, aby zapewnić ochronę Państwa motocykla podczas ślizgu, przy pokonywaniu zakrętu lub upadku. Crash pady Womet-tech są produkowane przez firmę specjalizującą się w tego typu produktach. Charakteryzują się wytrzymałością na silne uderzenia, nie są łamliwe i bardzo dobrze pochłaniają energię uderzenia. Wielu Motocyklistów wybrało i przetestowało nasze produkty, pozytywnie oceniając ich jakość!

Przed rozpoczęciem pracy należy przeczytać uważnie całą instrukcję. Jeśli nie są państwo pewni montażu zaleca się kontakt z serwisem.

Zestaw zawiera:

2x crash pad z aluminiową tuleją wewnątrz
2X tuleja aluminiowa ustalająca
2x adapter aluminiowy 7075
2x śruba imbusowa M 10x50 mm wraz z podkładką
1x śruba stalowa M 12x60 mm wraz z podkładką
1x śruba stalowa M 12x100 mm wraz z podkładką
2x zaśleпка*

Potrzebne klucze:

Klucz nasadowy 12 mm
Klucz imbusowy 8 mm z dynamometrem
klucz imbusowy 5mm .

Prawa i lewa strona są różne !



Lewa strona



Prawa strona

Instrukcja:

Lewa strona, (gdy siedzisz na motocyklu)

1. Przed rozpoczęciem zdemonstuj boczną owiewkę za pomocą klucza imbusowego 5mm.
2. Odkręć śrubę mocującą silnik za pomocą klucza nasadowego 12mm.
3. Zamontuj dłuższy adapter używając śruby M12x60mm.
4. Zamontuj Cash pad wraz z tuleją ustalającą dłuższą używając śruby M10x50mm.
5. Śrubę dokręć według zaleceń książki serwisowej.
6. Zamontuj owiewkę.

Prawa strona, (gdy siedzisz na motocyklu)

1. Przed rozpoczęciem zdemonstuj boczną owiewkę za pomocą klucza imbusowego 5mm .
2. Odkręć śrubę mocującą silnik za pomocą klucza nasadowego 12mm.
3. Zamontuj krótszy adapter używając śruby M12x100mm.
4. Zamontuj Cash pad wraz z tuleją ustalającą krótszą używając śruby M10x50mm.
5. Śrubę dokręć według zaleceń książki serwisowej.
6. Zamontuj owiewkę.

Gwarancja i ograniczenie odpowiedzialności.

Firma Womet- tech zastrzega sobie prawo do zmiany projektu bez wpływu na działanie czy estetykę Produktów i dostarczenie ich w takim stanie który będzie zgodny z zamówieniem. Kupujący uznaje, że żadnego rodzaju oświadczenie ani zapewnienie, inne niż wymienione w zamówieniu i jego potwierdzeniu, nie zostało złożone i nie będzie stosowane względem Produktów. Kupujący , dokonując zakupu Produktu, potwierdza jego jakość handlową oraz przydatność do określonego celu. Kupujący jest odpowiedzialny za zapewnienie nienaruszenia gwarancji motocykla podczas montowania Produktów. Wszystkie produkty rozprowadzane przez Womet-tech są opatrzone gwarancją dotyczącą wyłącznie wad materiałowych i wad wykonania. Wszelkie reklamacje zostaną rozpatrzone bezzwłocznie i rzetelnie. Przy zwrocie Produktów z usterką Womet-tech zapewnia ich wymianę lub zwrot pieniędzy tylko w przypadku, jeżeli Produkt nie podlegał jakiegokolwiek modyfikacji i był wykorzystywany zgodnie z instrukcjami lub zaleceniami producenta oraz jeżeli wada nie powstała na skutek wypadku lub zaniedbania. Producent nie ponosi odpowiedzialności za szkody na osobie oraz szkody na mieniu jak również szkody pośrednie wynikające z testowania oraz użytkowania produktów.

Tel.12-350-41-05
www.womet-tech.pl
e-mail biuro@womet-tech.pl

* Dostępne opcjonalnie. Od 2013r dołączone do zestawu.

Crash Protector Kit Installation Instructions for YAMAHA YZF R1 09- CODE: CPY22S

Thank you for purchasing the Crash Protectors for YAMAHA YZF R1. They were designed for effective protection of your motorcycle against damage when sliding, taking bends or crashing. Womet-tech Crash Protectors are manufactured by the company specializing in such products. They are strong impact resistant, flexible and able to dissipate the crash impact. Our Crash Protectors have been used and recommended by many motorcyclists!

It is essential to read the entire Installation Instructions carefully. If in any case you are not certain of how to install the kit, contact service.

Parts included:

2x crash protector with aluminium bushing inside
2x aluminium spacer
2x aluminium adapter 7075
2x M10x50 mm Allen bolt with washer
1x M12x60 mm steel bolt with the washer
1x M12x100 mm steel bolt with the washer
2x plastic cap with sticker*

Tools required:

12 mm torque wrench
8 mm Allen wrench
5 mm Allen wrench



Instructions:

Left side (when sitting on a bike)

1. Remove the side wind deflector before commencing work. Use 5 mm Allen wrench.
2. Remove the mount bolt of the engine. Use 12 mm Allen wrench.
3. Mount the longer aluminium adapter. Use M12x60 mm bolt.
4. Mount crash protector with the longer aluminium spacer. Use M10x50 mm bolt.
5. Tighten it with factory recommendation.
6. Mount the side wind deflector.

Right side (when sitting on a bike)

1. Remove the side wind deflector before commencing work. Use 5 mm Allen wrench.
2. Remove the mount bolt of the engine. Use 12 mm Allen wrench.
3. Mount the shorter aluminium adapter. Use M12x100 mm bolt.
4. Mount crash protector with the longer aluminium spacer. Use M10x50 mm bolt.
5. Tighten it with factory recommendation.
6. Mount the side wind deflector.

Guarantee and limitation of liability

Womet-tech reserves the right to modify the design, however without influencing any functions or aesthetics of the Products and to deliver them in a condition that complies with the order. Whereas, the Buyer acknowledges that any statement or guarantee other than stated in the order and its confirmation has not been made and shall not be applied to the Products. The Buyer, by purchasing the Product recognizes its commercial quality and its specific usability. The Buyer is responsible for any damages to the motorcycle caused during the installation of Products. All Products distributed by Womet-tech are covered by the guarantee against defects in the material and in manufacturing solely. All complaints shall be addressed immediately and properly. In case faulty Products are returned, Womet-tech guarantees the replacement of such Products or the refund, providing that the Product was not modified in any way and was used in compliance with the instructions or manufacturer's recommendations and if the fault was not caused by neglect or accident. The manufacturer does not bear the liability for any damages either to the person or property or damages resulting from testing or normal wear and tear of Products.

Phone: 12-350-41-05

www.womet-tech.pl

e-mail biuro@womet-tech.pl

* Available optionally. Included to the kit from 2013.